

# DART SERVICE INSTRUCTION

TO AMEND INSTALLATION INSTRUCTIONS D350-591 REV. G OR EARLIER AND  
INSTRUCTIONS FOR CONTINUED AIRWORTHINESS ICA-D350-591 REV. 3 OR EARLIER

REF CANADIAN STC: SH92-6  
REF FAA STC: SH967NE

## 1.0 PURPOSE

The DSI 9670-011 Step Modification Kit has been made available for operators who would like to lower a D350-591-121/-122 High Skid Step Assembly to improve compatibility with a D350-607-XXX Basket installation.

The DSI 9670-013 Step Modification Kit has been made available for operators who would like to lower a D350-591-213/-214/-311/-312 High Skid Step Assembly to improve compatibility with a D350-607-XXX Basket installation.

## 2.0 INSTALLATION

### 2.1 FOR D350-591-121/-122 High Skid Step Assembly

2.1.1 Remove the Step Assembly from the aircraft. Retain all fasteners.

2.1.2 Remove qty (16) rivets fastening Step Leg Assembly D2582 to the D2351-041/-042 Step Assembly. See Figure 1. Drill a  $\varnothing$  0.25" hole in the bottom of the step 0.25" from the forward end. Hold the step vertically with the hole end down. Inject Sikaflex/Proseal into the hole to 'capture' any rivet stems inside the step and cover the drilled hole. Allow to cure before proceeding.

2.1.3 Install Mid Step Leg Assembly D4964-041 using qty (16) NASM20600AD4W4 rivets, (8 per side). See Figure 2.

2.1.4 Touch up paint finish as required with chemical film material (Alodine 1200 or 1201) per MIL-C-5541, one coat of MIL-P-85582 or MIL-P-23377 primer, and 2-3 coats of MIL-C-85285 polyurethane coating to match original finish. Clean off any flaking anti-skid and touch up with Black Anti-Skid paint per MIL-W-5044 Type 2.

2.1.5 Re-install the Step Assembly on to the aircraft per ICA-D350-591.

### 2.2 FOR D350-591-213/-214/-311/-312 High Skid Step Assembly

2.2.1 Remove the Step Assembly from the aircraft. Retain all fasteners.

2.2.2 Remove qty (16) rivets fastening Step Leg Assembly D3065-041 and Spacer D3066-1 (2 PL) to D3078-041/-042 Step Assy or D3272-041/-042 Step Assy. Retain Spacer D3066-1 (2). See Figure 1. Drill a  $\varnothing$  0.25" hole in the bottom of the step 0.25" from the forward end. Hold the step vertically with the hole end down. Inject Sikaflex/Proseal into the hole to 'capture' any rivet stems inside the step and cover the drilled hole. Allow to cure before proceeding

2.2.3 Install Mid Step Leg Assembly D4964-043 and Spacer D3066-1 using qty (16) NASM20600AD4W4 rivets, (8 per side). See Figure 3.

2.2.4 Touch up paint finish as required with chemical film material (Alodine 1200 or 1201) per MIL-C-5541, one coat of MIL-P-85582 or MIL-P-23377 primer, and 2-3 coats of MIL-C-85285 polyurethane coating to match original finish. Clean off any flaking anti-skid and touch up with Black Anti-Skid paint per MIL-W-5044 Type 2.

2.2.5 Re-install the Step Assembly on to the aircraft per ICA-D350-591.

## 3.0 WEIGHT AND BALANCE

There is negligible weight change with this modification.

CANADA  
DEPARTMENT OF TRANSPORT  
AIRCRAFT CERTIFICATION  
BRANCH  
DAO # 01-O-01

APPROVED

BY:

D. SHEPHERD (DE # 02)

DATE: 13.10.30  
CERT. NO.: SH92-6  
ISSUE NO.: 11

A	NEW ISSUE	DB	13.10.30
REV.	DESCRIPTION	BY	DATE
DESIGN	DB	DART AEROSPACE LTD	
DRAWN	DB	HAWKESBURY, ONTARIO, CANADA	
CHECKED	DB	DRAWING NO.	REV. A
MFG. APPR.	N/A	DSI 9670	SHEET 1 OF 3
APPROVED	160	TITLE	SCALE
DE APPR.	SH	HIGH SKID MID STEP MODIFICATION KIT	NTS
DATE	13.10.30	COPYRIGHT © 2013 BY DART AEROSPACE LTD THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.	

#### 4.0 PARTS LIST

##### FOR D350-591-121/-122 High Skid Step Assembly (FIGURE 2)

ITEM	QTY -011	P/N	DESCRIPTION
	X	DSI 9670-011	STEP MODIFICATION KIT
1	1	D4964-041	MID STEP LEG ASSY
2	16	NASM20600AD4W4	RIVET

##### FOR D350-591-213/-214/-311/-312 High Skid Step Assembly (FIGURE 3)


ITEM	QTY -013	P/N	DESCRIPTION
	X	DSI 9670-013	STEP MODIFICATION KIT
1	1	D4964-043	MID STEP LEG ASSY
2	16	NASM20600AD4W4	RIVET

DESIGN	DB	<b>DART AEROSPACE LTD</b> HAWKESBURY, ONTARIO, CANADA	REV. A
DRAWN	DB		
CHECKED	13	DRAWING NO.	SHEET 2 OF 3
MFG. APPR.	N/A	DSI 9670	
APPROVED	140	TITLE	SCALE
DE APPR.	141	HIGH SKID MID STEP MODIFICATION KIT	NTS
DATE	13.10.30	COPYRIGHT © 2013 BY DART AEROSPACE LTD <small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.</small>	

REMOVE RIVETS  
8 PL PER SIDE

D2582 STEP LEG ASSY  
OR  
D3065-041 STEP LEG ASSY

REMOVE AND RETAIN  
EXISTING HARDWARE



**FIGURE 1**


(EXISTING D350-591-121/-122/-213/-214/-311/-312 CONFIGURATION REMOVAL)

NASM20600AD4W4  
8 PL PER SIDE

DRILL  $\varnothing 0.25$  HOLE,  
THIS END

D4964-041 MID STEP  
LEG ASSY

RE-INSTALL USING  
EXISTING HARDWARE



**FIGURE 2: DSI 9670-011 CONFIGURATION**


(TO MODIFY D350-591-121/-122 STEPS)

NASM20600AD4W4  
8 PL PER SIDE


DRILL  $\varnothing 0.25$  HOLE,  
THIS END

D4964-043 MID STEP  
LEG ASSY

RE-INSTALL USING  
EXISTING HARDWARE



RE-INSTALL  
D3066-1 SPACER



**FIGURE 3: DSI 9670-013 CONFIGURATION**

(TO MODIFY D350-591-213/-214/-311/-312 STEPS)

DESIGN	DB	<b>DART AEROSPACE LTD</b> HAWKESBURY, ONTARIO, CANADA	
DRAWN	DB		
CHECKED	<i>[Signature]</i>	DRAWING NO. <b>DSI 9670</b>	REV. A
MFG. APPR.	N/A	SHEET 3 OF 3	
APPROVED	<i>[Signature]</i>	TITLE	SCALE
DE APPR.	<i>[Signature]</i>	<b>HIGH SKID MID STEP MODIFICATION KIT</b>	NTS
DATE	<b>13.10.30</b>	COPYRIGHT © 2013 BY DART AEROSPACE LTD <small>THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.</small>	